











The Simplest Workflow

BACS™ Microbubbles Comparison for Dead Cell Removal



Magnetics	Microfluidics	BACS™
 Prep Required? Yes	 Prep Required? Yes	 Prep Required? No
 # of Samples 4 per run Minimum Cell # 1M or more	 # of Samples 1 per run Minimum Cell # 1 to 2M	 # of Samples Up to 24+ per run Minimum Cell # 500k or lower
 Columns Cartridges? Yes Additional Equipment? Yes Instruments? No	 Columns Cartridges? Yes Additional Equipment? No Instruments? Yes	 Columns Cartridges? No Additional Equipment? No Instruments? No

MORE SAMPLES, LESS TIME



UNCOVER MORE MEANINGFUL BIOLOGY

Tired of damaged cells? Our gentle workflow isolates cells in their natural state.

ENJOY HIGHER RECOVERY

Keep more cells of interest with our industry-leading microbubble protocol to perform more studies for greater depth of knowledge.

FREE YOURSELF FROM LIMITATION

No longer worry about being limited by magnets, losing cells to clogged columns, or purchasing costly equipment.